


Spare Parts
High Pressure Spray Gun ST-3600
Item-No. 20 3600 610



| Pos. | Item-No. | Description | Pos. | Item-No. | Description |
|------|-------------|-------------------------|------|-------------|---------------------------|
| 1 | 04 0001 310 | Stainless housing | 15 | 05 0000 300 | O-ring 10.82 x 1.78 |
| 2 | 04 0006 810 | Outlet 1/4 NPT | 16 | 05 0000 960 | back up ring |
| 3 | 04 0000 512 | Seal hub | 17 | 05 0001 026 | Back ring |
| 4 | 04 0000 495 | Valve cone | 18 | 05 0001 021 | O-ring 17 x 15 |
| 5 | 04 0002 257 | Sealing cap | 19 | 05 0001 025 | O-ring 18 x 15 |
| 6 | 04 0000 060 | Pin 5x20 | 20 | 05 0000 126 | Supporting ring 11,8x14x1 |
| 7 | 02 0001 126 | Plastic housing | 21 | 05 0001 521 | O-ring 10x1,5 |
| 8 | 02 0001 151 | Plastic cover | 22 | 04 0006 910 | Inlet - nut 3/8 NPT |
| 9 | 04 0002 258 | Sealing plate | 23 | 04 0000 051 | Screw 3.5x16 |
| 10 | 06 0000 525 | Spring | 24 | 02 0001 181 | Blind Plug |
| 11 | 20 2000 032 | Trigger with safety pin | 25 | 04 0005 532 | Inlet Pipe |
| 12 | 04 0007 045 | Position pin | 26 | 05 0000 126 | Supporting ring 11,8x14x1 |
| 13 | 02 0001 110 | Label | 27 | 05 0001 521 | O-ring 10x1,5 |
| 14 | 05 0000 967 | Gasket ring | | | |

Repair-Kits

| Pos. | Item-No. | Description | Pos. | Item-No. | Description |
|------|-------------|--------------------|------|----------|-------------|
| * | 20 3600 490 | Repair-Kit ST-3600 | | | |